

Operation Instructions for 2.4G Wireless Remote Controller

Instructions for wireless remote controller

- Code Matching and Grouping** (once they are code matched with each other, these can be controlled remotely together)
Turn on selective lights as one group (for example Group 1), press "on" button for this group within 5 seconds after turning on these lights. The selective lights are successfully grouped after they are flickering.
- Code Clearing and Re-grouping**
Turn on selective lights, press "on" button of the current group 5 times within 5 seconds, this will clear the code matching of selective lights. Re-grouping as the code matching as the first step.
- Synchronization and control by group function**
Press "Full on" "Full off", the 4 groups light on/off function will be controlled simultaneously. Press "on" "off" button of the selected group, the lights will be controlled separately by group with any key.
- Brightness control "Brighter" "Darker"**
Short press the button to control brightness as single-stage adjustment Long press the button to control brightness as continuous adjustment
- CCT control "Colder" "Warmer"**
Short press the button to control CCT as single-stage adjustment Long press the button to control CCT as continuous adjustment
- Night light Mode**
Long press "Full off", all groups will turn into night light mode.
Long press "off" of the selected group, the lights of this group will turn into night light mode
- Timing shutdown**
Long press "on" button of the selected group, lights turn into timing shutdown function successfully after one-time flicker. Lights in this group will shut down automatically after 30S.

